

# Viewing Loupe System




Compatible camera's	loupe set	Base and frame	Frame only
---------------------	-----------	----------------	------------

**Canon**  
1D-MKIV, 5D-MKII, 6D, 7D, 60D,  
650D, 600D, 550D, EOS-M

**Nikon**  
D3-s, D300-s, D90, D7000, D3200

**PENTAX**  
K-5IIs, K5, K-7, K-30, K-01, K-r, K-x



CS-30  
Loupe viewer and 3.0" adhesive frame


No base



CS-390  
3.0" adhesive frame


**Canon**  
1DX, 1DC, 5D-MKIII, 6D, EOS-M

**Nikon**  
D4, D800, D800E, D600



CS-28  
Loupe viewer and 3.2" adhesive frame

No base




CS-391  
3.2" adhesive frame


**Canon**  
7D, 60D, 650D, 600D, 550D, EOS-M

**Nikon**  
D90, D5200, D5100, D3200, D7000

**PENTAX**  
K-5IIs, K5, K-7, K-30, K-01, K-r, K-x



CS-32  
Loupe viewer, base and 3.0" frame




CS-35  
Base and 3.0" frame




CS-302  
3.0" frame

**Canon**  
5D-MKII, 6D

**Nikon**  
D300-s



CS-33  
Loupe viewer, base and 3.0" frame



CS-36  
Base and 3.0" frame




CS-303  
3.0" frame


# Viewing Loupe System

**Canon**  
5D-MKIII, 6D


**Nikon**  
D800, D800E



CS-31  
Loupe viewer, base and 3.2" frame




CS-38  
Base and 3.2" frame




CS-305  
3.2" frame


**Canon**  
1D-MKIV



CS-34  
Loupe viewer, base and 3.0" frame




CS-37  
Base and 3.0" frame




CS-304  
3.0" frame

**Canon**  
1D-X, 1D-C


**Nikon**  
D4



CS-29  
Loupe viewer, base and 3.2" frame



CS-39  
Base and 3.2" frame



CS-306  
3.2" frame

# Viewing Loupe System



SET LOUPE+BASE+FRAME	CS-30	CS-28	CS-32	CS-33	CS-31	CS-34	CS-29
SET BASE+FRAME	-	-	CS-35	CS-36	CS-38	CS-37	CS-39
FRAME	CS-390	CS-391	CS-302	CS-303	CS-305	CS-304	CS-306
<b>Canon</b>							
1DX		•					•
1DC		•					•
1D-MKIV	•					•	
5D-MKIII		•			•		
5D-MKII	•			•			
6D		•			•		
7D	•			•			
60D	•		•				
650D	•		•				
600D	•		•				
550D	•		•				
EOS-M	•		•				
<b>Nikon</b>							
D4		•					•
D3-s		•					
D800-E		•			•		
D800		•			•		
D600		•			•		
D300-s	•			•			
D90	•		•				
D7000	•		•				
D5200			•				
D5100			•				
D3200	•		•				
<b>PENTAX</b>							
K-5IIs	•		•				
K5	•		•				
K-7	•		•				
K-30	•		•				
K-01	•		•				
K-r	•		•				
K-x	•		•				

Cambo Photographic Industry B.V. / Cambo Video and Broadcast Products B.V.

This instruction manual is prepared with care, although no responsibility, financial or otherwise, is accepted for any consequences related the information stated in this instruction manual. All specifications in this instruction manual are subject to change without notice.

